Beauty Bed

INSTRUCTION MANUAL

Welcome to use our beauty bed, before use the bed, please read the user manual carefully, Thank you.

Technical Data



Item No.	Net Weight	Max Load	Input Voltage	Output Voltage
UR-B1856	100 kg	200 kg	AC 110~230V 50~60Hz	DC 24V

Introduction For Control Panel



The motorized eyelash bed remote control allows precise adjustments of bed height, backrest angle, and footrest position when the device is powered on.

① Backrest Angle Adjustment: Left-side ↑ / Right-side ↓
② Bed Height Adjustment: Left-side ↑ / Right-side ↓
③ Leg rest position adjustment: Left-side ↑ / Right-side ↓
④ Single-button control（Backrest、Leg rest）
⑤ Light control switch



Button ①
Control Area



Button ②
Control Area



Button ③
Control Area

Height Adjustment



Adjustment



Maintenance & Care

1. Clean the surface with a damp cloth.
2. For deeper cleaning, use mild soap mixed with water.
3. Do NOT use harsh scrub cleaners.

Technical Troubleshooting Guide

Issue	Possible Causes	Solutions
*Button Unresponsive *Buzzer Sound/Buzzing	1.The control button has reached its functional maximum. 2.Verify power plug connectivity status. 3.Inspect all transformer terminal engagements.	1.Attempt to press other control buttons. 2.Disconnect and reconnect the power plug. 3.Disconnect and reconnect all ports connected to the transformer.

Product Care



Regularly remove hair and debris



Wipe the surface with a damp cloth or use a mild aqueous soap solution.



Avoid using corrosive cleaners, bleach, or detergents.



Do not remove upholstery for cleaning.

Warranty Statement

The warranty period is one (1) year. We warrant to you, the original purchaser, that the product shall be free from defects in material and/or workmanship under normal use for a period of twelve (12) months from the date the product is received. Damage resulting from improper handling or exposure to harsh weather conditions after delivery is expressly excluded from this warranty.
For additional information, contact our Technical Support Team.